

beschrijving	type	afmeting platform lengte x breedte
--------------	------	---------------------------------------

Mercedes

	Mercedes Sprinter H1 - L1	EasyLoader 1B	1500x1300mm
x	Mercedes Sprinter H1 - L2	EasyLoader 1B	1500x1300mm
x	Mercedes Sprinter H2 - L1	EasyLoader 1A	1500x1300mm
	Mercedes Sprinter H2 - L2	EasyLoader 1A	1500x1300mm
	Mercedes Sprinter H2 - L3	EasyLoader 1A	1500x1300mm
x	Mercedes Sprinter H2 - L4	EasyLoader 1A	1500x1300mm
	Mercedes Sprinter H3 - L2	EasyLoader 1A	1500x1300mm
	Mercedes Sprinter H3 - L3	EasyLoader 1A	1500x1300mm
	Mercedes Sprinter H3 - L4	EasyLoader 1A	1500x1300mm

Let op bij de H3 wordt het laadplatform op de zelfde hoogte opgeborgen als bij de H2

	Mercedes Vito H1 - L2	EasyLoader 2A	1200x1200mm
	Mercedes Vito H1 - L3	EasyLoader 2A	1200x1200mm

Volkswagen

	Volkswagen crafter H1 - L1	EasyLoader 1B	1500x1300mm
x	Volkswagen crafter H1 - L2	EasyLoader 1B	1500x1300mm
x	Volkswagen crafter H2 - L1	EasyLoader 1A	1500x1300mm
	Volkswagen crafter H2 - L2	EasyLoader 1A	1500x1300mm
	Volkswagen crafter H2 - L3	EasyLoader 1A	1500x1300mm
x	Volkswagen crafter H2 - L4	EasyLoader 1A	1500x1300mm
	Volkswagen crafter H3 - L2	EasyLoader 1A	1500x1300mm
	Volkswagen crafter H3 - L3	EasyLoader 1A	1500x1300mm
	Volkswagen crafter H3 - L4	EasyLoader 1A	1500x1300mm

Let op bij de H3 wordt het laadplatform op de zelfde hoogte opgeborgen als bij de H2

Renault

	Renault Master H1 - L1	EasyLoader 1B	1500x1300mm
x	Renault Master H2 - L1	EasyLoader 1A	1500x1300mm
	Renault Master H2 - L2	EasyLoader 1A	1500x1300mm
	Renault Master H2 - L3	EasyLoader 1A	1500x1300mm
	Renault Master H3 - L2	EasyLoader 1A	1500x1300mm
	Renault Master H3 - L3	EasyLoader 1A	1500x1300mm

Bij de H3 aanpassing dak, 3 uur werk extra

	Renault Trafic H1 - L1	EasyLoader 2A	1200x1200mm
	Renault Trafic H1 - L2	EasyLoader 2A	1200x1200mm
	Renault Trafic H2 - L1	EasyLoader 2B	1200x1200mm
	Renault Trafic H2 - L2	EasyLoader 2B	1200x1200mm

Opel

	Opel Movano H1 - L1	EasyLoader 1B	1500x1300mm
X	Opel Movano H2 - L1	EasyLoader 1A	1500x1300mm
	Opel Movano H2 - L2	EasyLoader 1A	1500x1300mm
	Opel Movano H2 - L3	EasyLoader 1A	1500x1300mm
	Opel Movano H3 - L2	EasyLoader 1A	1500x1300mm
	Opel Movano H3 - L3	EasyLoader 1A	1500x1300mm

Bij de H3 aanpassing dak, 3 uur werk extra

	Opel Vivaro H1 - L1	EasyLoader 2A	1200x1200mm
	Opel Vivaro H1 - L2	EasyLoader 2A	1200x1200mm

	Opel Vivaro H2 - L1	EasyLoader 2B	1200x1200mm
	Opel Vivaro H2 - L2	EasyLoader 2B	1200x1200mm

Nissan

	Nissan Interstar H1 - L1	EasyLoader 1B	1500x1300mm
X	Nissan Interstar H2 - L1	EasyLoader 1A	1500x1300mm
	Nissan Interstar H2 - L2	EasyLoader 1A	1500x1300mm
	Nissan Interstar H2 - L3	EasyLoader 1A	1500x1300mm
	Nissan Interstar H3 - L2	EasyLoader 1A	1500x1300mm
	Nissan Interstar H3 - L3	EasyLoader 1A	1500x1300mm

Bij de H3 aanpassing dak, 3 uur werk extra

	Nissan Primastar H1 - L1	EasyLoader 2A	1200x1200mm
	Nissan Primastar H1 - L2	EasyLoader 2A	1200x1200mm
	Nissan Primastar H2 - L1	EasyLoader 2B	1200x1200mm
	Nissan Primastar H2 - L2	EasyLoader 2B	1200x1200mm

Citroen

X	Citroen Jumper H1 - L1	EasyLoader 1B	1500x1300mm
	Citroen Jumper H1 - L2	EasyLoader 1B	1500x1300mm
	Citroen Jumper H2 - L2	EasyLoader 1A	1500x1300mm
X	Citroen Jumper H2 - L3	EasyLoader 1A	1500x1300mm
X	Citroen Jumper H2 - L4	EasyLoader 1A	1500x1300mm
	Citroen Jumper H3 - L3	EasyLoader 1A	1500x1300mm
X	Citroen Jumper H3 - L4	EasyLoader 1A	1500x1300mm

Peugeot

X	Peugeot Boxer H1 - L1	EasyLoader 1B	1500x1300mm
	Peugeot Boxer H1 - L2	EasyLoader 1B	1500x1300mm
	Peugeot Boxer H2 - L2	EasyLoader 1A	1500x1300mm
X	Peugeot Boxer H2 - L3	EasyLoader 1A	1500x1300mm
X	Peugeot Boxer H2 - L4	EasyLoader 1A	1500x1300mm
	Peugeot Boxer H3 - L3	EasyLoader 1A	1500x1300mm
X	Peugeot Boxer H3 - L4	EasyLoader 1A	1500x1300mm

Fiat

X	Fiat Ducato H1 - L1	EasyLoader 1B	1500x1300mm
	Fiat Ducato H1 - L2	EasyLoader 1B	1500x1300mm
	Fiat Ducato H2 - L2	EasyLoader 1A	1500x1300mm
X	Fiat Ducato H2 - L3	EasyLoader 1A	1500x1300mm
X	Fiat Ducato H2 - L4	EasyLoader 1A	1500x1300mm
	Fiat Ducato H3 - L3	EasyLoader 1A	1500x1300mm
X	Fiat Ducato H3 - L4	EasyLoader 1A	1500x1300mm

Ford

Let op Ford transit alleen voorwielaandrijving (FDW)

	Ford Transit SWG - SHD (L1 - H2)	EasyLoader 1B	1500x1300mm
	Ford Transit MWG - SHD (L2 - H2)	EasyLoader 1B	1500x1300mm
	Ford Transit LWG - SHD (L3 - H2)	EasyLoader 1B	1500x1300mm
X	Ford Transit SWG - HD (L1 - H3)	EasyLoader 1A	1500x1300mm
X	Ford Transit MWG - HD (L2 - H3)	EasyLoader 1A	1500x1300mm
X	Ford Transit LWG - HD (L3 - H3)	EasyLoader 1A	1500x1300mm

Iveco

X	Iveco Daily 29 / 35 H2 - L2 (3000L)	EasyLoader 1A	1500x1300mm
	Iveco Daily 29 / 35 H2 - L3 (3300)	EasyLoader 1A	1500x1300mm
X	Iveco Daily 29 / 35 H2 - L4 (3950)	EasyLoader 1A	1500x1300mm

Let op auto`s met opstapbumper gaat niet (Sprinter - Crafter - Transit)

Levertijd 2 weken

Type waar een kruisje voor staat moeten nog worden ingepast levertijd in overleg met EasyLoader Nederland